

K&H Bird Bath AutoFill™

Care & Instructions

Tank Made in the USA | Base Made in China
 K&H Manufacturing, LLC
 Colorado Springs, CO
 www.khmfg.com | (877) 738-5188



Thank you for purchasing the K&H Bird Bath AutoFill™ by K&H Manufacturing. When used correctly, the K&H Bird Bath AutoFill™ will keep virtually any open-style bird bath full for up to a week at a time!

READ CAREFULLY:

Your new K&H BIRD BATH AUTOFILL™ can be adjusted to keep from 1" to 2.5" water depth in your bird bath. Ten adjustment feet have been included with your K&H Bird Bath AutoFill™.

Use the following chart to determine the necessary adjustments:

1" desired water depth	Use K&H Bird Bath AutoFill™ as is. No adjustment necessary.
1.75" desired water depth	Insert 1 adjustment foot into each hole in bottom of K&H Bird Bath AutoFill™ device.
2.5" desired water depth	Insert 2 adjustment feet into each hole in bottom of K&H Bird Bath AutoFill™ device.

INSTRUCTIONS:

- 1** Remove the reservoir tank cap.
- 2** Insert the plastic plug into the hole in the cap.
- 3** Fill the reservoir tank with fresh water.
- 4** Snuggly screw the cap onto the reservoir tank.
- 5** The tank should now be able to be carried spill-free to desired location.

- 6** Place the Bird Bath AutoFill™ base into the bird bath, ensuring bird bath is somewhat level.
- 7** Set the filled reservoir tank onto AutoFill base. Water should automatically release.
- 8** After initial fill of the bird bath, you may want to remove the reservoir tank and refill it. Your bird bath will now remain filled to your desired pre-set level.

NOTE:

If your bird bath is not level and water spills over the edge, your K&H Bird Bath AutoFill™ will continue releasing water until empty. Ensure your bird bath is level and will not overflow.

K&H Limited One Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.

K&H Bird Bath AutoFill™

Care & Instructions

Tank Made in the USA | Base Made in China
 K&H Manufacturing, LLC
 Colorado Springs, CO
 www.khmfg.com | (877) 738-5188



Thank you for purchasing the K&H Bird Bath AutoFill™ by K&H Manufacturing. When used correctly, the K&H Bird Bath AutoFill™ will keep virtually any open-style bird bath full for up to a week at a time!

READ CAREFULLY:

Your new K&H BIRD BATH AUTOFILL™ can be adjusted to keep from 1" to 2.5" water depth in your bird bath. Ten adjustment feet have been included with your K&H Bird Bath AutoFill™.

Use the following chart to determine the necessary adjustments:

1" desired water depth	Use K&H Bird Bath AutoFill™ as is. No adjustment necessary.
1.75" desired water depth	Insert 1 adjustment foot into each hole in bottom of K&H Bird Bath AutoFill™ device.
2.5" desired water depth	Insert 2 adjustment feet into each hole in bottom of K&H Bird Bath AutoFill™ device.

INSTRUCTIONS:

- 1** Remove the reservoir tank cap.
- 2** Insert the plastic plug into the hole in the cap.
- 3** Fill the reservoir tank with fresh water.
- 4** Snuggly screw the cap onto the reservoir tank.
- 5** The tank should now be able to be carried spill-free to desired location.

- 6** Place the Bird Bath AutoFill™ base into the bird bath, ensuring bird bath is somewhat level.
- 7** Set the filled reservoir tank onto AutoFill base. Water should automatically release.
- 8** After initial fill of the bird bath, you may want to remove the reservoir tank and refill it. Your bird bath will now remain filled to your desired pre-set level.

NOTE:

If your bird bath is not level and water spills over the edge, your K&H Bird Bath AutoFill™ will continue releasing water until empty. Ensure your bird bath is level and will not overflow.

K&H Limited One Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.