

# Thermo-Pond 3.0™

## Care & Instructions

Made in China  
K&H Manufacturing, LLC  
Colorado Springs, CO  
www.khmf.com | (877) 738-5188  
**Patent 6,597,863**



**Thank you for purchasing a Thermo-Pond 3.0™. The Thermo-Pond 3.0™ is made for years of dependable service when used as directed and cared for properly.**

**WARNING:** This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock of fire which could cause serious bodily injury.

### 1 Directions for use:

Just plug in your Thermo-Pond 3.0™ and float it in your pond dome side up. You should begin to use your Thermo-Pond 3.0™ when your pond has iced over.

### 2 Directions for use if your pond is already frozen over:

If the ice on your pond is more than 2 inches thick, drill a hole with an ice auger and place the Thermo-Pond 3.0™ over the hole.

If the ice is only 1 or 2 inches thick, place the Thermo-Pond 3.0™ on the ice and it will melt its way through the ice. Do not chop through the ice in smaller ponds as the shock waves can damage or kill your fish.

### 3 Storing your de-icer:

After the winter season, wipe down your Thermo-Pond 3.0™ with a damp cloth and store in a clean dry place. Always inspect your Thermo-Pond 3.0™ before using. If there are cracks in the cord or plastic housing, do not use, discard immediately. Please consult your pond professional on tips for overwintering fish.

**WARNING:** HEATING ELEMENT MUST BE SUBMERGED UNDER WATER AT ALL TIMES when the de-icer is in use!

- Make sure the cord is placed properly to ensure the de-icer floats level when using as a floating de-icer.
- Never allow pond to run dry.

## IMPORTANT SAFEGUARDS

**When using electrical appliances, basic safety precautions should always be followed including the following:**

- Always keep safety your number one priority
- Never walk on thin ice. Position your Thermo-Pond 3.0™ within arm's reach of shore to avoid walking on thin ice
- Snow and ice should be removed from the top of your Thermo-Pond 3.0™
- Thermo-Pond 3.0™ is recommended for ponds up to 1,000 gallons. An additional Thermo-Pond 3.0™ should be used for each additional 1,000 gallons of water.
- An additional Thermo-Pond 3.0™ should also be used in ponds requiring extra gas exchange due to excessive plant decay or large quantities of fish under the ice.
- Always inspect your Thermo-Pond 3.0™ before using. If there are cracks in the cord or plastic housing, do not use, discard immediately.
- Please consult your pond professional on tips for overwintering fish.

### K&H Limited One Year Warranty

**Our warranty is as follows:** K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

**To exercise your warranty:** If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.